OPERATOR'S MANUAL

SONIC WINGS™
ソニックウィングス

AERO FIGHTERS™

取扱説明書

Power Supply	DC+5V DC+12V
Monitor	Vertical Screen
Game Style	2-Player Simultaneous

SYSTEM V VIDEO SYSTEM Co.,Ltd.

©VIDEO SYSTEM 1992.

CONNECTOR DIAGRAM

SOLDER SIDE	NO.	NO.	PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	
SPEAKER (−)	L	10	SPEAKER (+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN SW 2	T	16	COIN SW 1
2-P START	U	17	1-P START
2-P UP	V	18	1-P UP
2-P DOWN	W	19	1-P DOWN
2-P LEFT	X	20	1-P LEFT
2-P RIGHT	Y	21	1-P RIGHT
2-P SW 1 BUTTON	Z	22	1-P SW 1 BUTTON
2-P SW 2 BUTTON	a	23	1-P SW 2 BUTTON
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND

HOW TO PLAY

■アメリカ、日本、スウェーデン、イギリスそれぞれ2人のパイロットの中から1人選び、ボタンで決定します。
■フルパワー時のみ弾数制限があります。
■自分の国を除く7つのステージをクリアするとエンディングです。

■Choose your player from U.S.A., JAPAN, SWEDEN and U.K.
■Full power for limited time.
■Game is over when you clear seven stages.

CONTROL PANEL



DIP-SWITCH 1

	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Coin Slot ● SAME	＊OFF							
● INDIVIDUAL	ON							
Coin 1 ● 1 COIN = 1 CREDIT		＊OFF	＊OFF	＊OFF				
● 2 COINS = 1 CREDIT		ON	OFF	OFF				
● 3 COINS = 1 CREDIT		OFF	ON	OFF				
● 1 COIN = 2 CREDITS		ON	ON	OFF				
● 1 COIN = 3 CREDITS		OFF	OFF	ON				
● 1 COIN = 4 CREDITS		ON	OFF	ON				
● 1 COIN = 5 CREDITS		OFF	ON	ON				
● 1 COIN = 6 CREDITS		ON	ON	ON				
Coin 2 ● 1 COIN = 1 CREDIT					＊OFF	＊OFF	＊OFF	
● 2 COINS = 1 CREDIT					ON	OFF	OFF	
● 3 COINS = 1 CREDIT					OFF	ON	OFF	
● 1 COIN = 2 CREDITS					ON	ON	OFF	
● 1 COIN = 3 CREDITS					OFF	OFF	ON	
● 1 COIN = 4 CREDITS					ON	OFF	ON	
● 1 COIN = 5 CREDITS					OFF	ON	ON	
● 1 COIN = 6 CREDITS					ON	ON	ON	
Continue Coin								
● NORMAL (START = 1 COIN, CONTINUE = 1 COIN)								＊OFF
● CONTINUE (START = 2 COINS, CONTINUE = 1 COIN)								ON

■ Continue Coin が CONTINUE の時は、DIP[2]～[7]の設定が無視されます。
■ With Continue "ON", two coins to play and one coin to continue, and other COIN/CREDIT option disabled.
■[1]～[8]が全て ON の時は、FREE PLAY mode になります。
■ FREE PLAY mode : Have [1]～[8] switches ON.

DIP-SWITCH 2

	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Screen Revers ● Normal	＊OFF							
● Invert	ON							
Demo Sound ● OFF		OFF						
● ON		＊ON						
Difficulty ● Normal			＊OFF	＊OFF				
● Easy			ON	OFF				
● Hard			OFF	ON				
● Super Hard			ON	ON				
Fighters ● 3					＊OFF	＊OFF		
● 1					ON	OFF		
● 2					OFF	ON		
● 4					ON	ON		
Extend Player ● 200,000							＊OFF	
● 300,000							ON	
Test Mode ● OFF								＊OFF
● ON								ON

■ Demo Sound が OFF の時は、コイン待ちデモの時に音が鳴らないようになります。
■ When DEMO-SOUND is "OFF", there will be no sound during demonstration mode.
＊出荷時の設定
＊ INDICATES FACTORY SETTING.

ビデオシステム株式会社 〒606 京都市左京区下鴨松ノ木町35-1 TEL.075(723)0358㈹ FAX.075(723)0368
OFFICE：35-1 Matsunoki-cho, Shimogamo, Sakyo-ku, Kyoto, Japan. 606.
TEL：075-723-0358 FAX：075-723-0368